# Chapter 1: The Basics of Illicit Discharges

An understanding of the nature of illicit discharges in urban watersheds is essential to find, fix and prevent them. This chapter begins by defining the terms used to describe illicit discharges, and then reviews the water quality problems they cause. Next, the chapter presents the regulatory context for controlling illicit discharges, and reviews the experience local communities have gained in detecting and eliminating them.

# 1.1 Important Terminology and Key Concepts

This Manual uses several important terms throughout the text that merit upfront explanation. This section defines the terminology to help program managers perform important illicit discharge detective work in their communities. Key concepts are presented to classify illicit discharges, generating sites and control techniques.

# Illicit Discharge

The term "illicit discharge" has many meanings in regulation and practice, but we use a four-part definition in this manual.

1. Illicit discharges are defined as a storm drain that has measurable flow during dry weather containing pollutants and/or pathogens. A storm drain with measurable flow but containing no pollutants is simply considered a discharge.

- 2. Each illicit discharge has a unique frequency, composition and mode of entry in the storm drain system.
- 3. Illicit discharges are frequently caused when the sewage disposal system interacts with the storm drain system. A variety of monitoring techniques is used to locate and eliminate illegal sewage connections. These techniques trace sewage flows from the stream or outfall, and go back up the pipes or conveyances to reach the problem connection.
- 4. Illicit discharges of other pollutants are produced from specific source areas and operations known as "generating sites." Knowledge about these generating sites can be helpful to locate and prevent non-sewage illicit discharges. Depending on the regulatory status of specific "generating sites," education, enforcement and other pollution prevention techniques can be used to manage this class of illicit discharges.

Communities need to define illicit discharges as part of an illicit discharge ordinance. Some non-storm water discharges to the MS4 may be allowable, such as discharges resulting from fire fighting activities and air conditioning condensate. Chapter 4 provides more detail on ordinance development.

<sup>&</sup>lt;sup>1</sup>40 CFR 122.26(b)(2) defines an illicit discharge as any discharge to an MS4 that is not composed entirely of storm water, except allowable discharges pursuant to an NPDES permit, including those resulting from fire fighting activities.

#### Storm Drain

A storm drain can be either an enclosed pipe or an open channel. From a regulatory standpoint, major storm drains are defined as enclosed storm drain pipes with a diameter of 36 inches, or greater or open channels that drain more than 50 acres. For industrial land uses, major drains are defined as enclosed storm drain pipes 12 inches or greater in diameter and open channels that drain more than two acres. Minor storm drains are smaller than these thresholds. Both major and minor storm drains can be a source of illicit discharges, and both merit investigation.

Some "pipes" found in urban areas may look like storm drains but actually serve other purposes. Examples include foundation drains, weep holes, culverts, etc. These pipes are generally not considered storm drains from a regulatory or practical standpoint. Small diameter "straight pipes," however, are a common source of illicit discharges in many communities and should be investigated to determine if they are a pollutant source.

Not all dry weather storm drain flow contains pollutants or pathogens. Indeed, many communities find that storm drains with dry weather flow are, in fact, relatively clean. Flow in these drains may be derived from springs, groundwater seepage, or leaks from water distribution pipes. Consequently, field testing and/or water quality sampling are needed to confirm whether pollutants are actually present in dry weather flow, in order to classify them as an illicit discharge.

# Discharge Frequency

The **frequency** of dry weather discharges in storm drains is important, and can be classified as *continuous*, *intermittent or transitory*.

Continuous discharges occur most or all of the time, are usually easier to detect, and typically produce the greatest pollutant load. Intermittent discharges occur over a shorter period of time (e.g., a few hours per day or a few days per year). Because they are infrequent, intermittent discharges are hard to detect, but can still represent a serious water quality problem, depending on their flow type. Transitory discharges occur rarely, usually in response to a singular event such as an industrial spill, ruptured tank, sewer break, transport accident or illegal dumping episode. These discharges are extremely hard to detect with routine monitoring, but under the right conditions, can exert severe water quality problems on downstream receiving waters.

### Discharge Flow Types

Dry weather discharges are composed of one or more possible **flow types**:

- Sewage and septage flows are produced from sewer pipes and septic systems.
- Washwater flows are generated from a
  wide variety of activities and operations.
  Examples include discharges of gray
  water (laundry) from homes, commercial
  carwash wastewater, fleet washing,
  commercial laundry wastewater, and
  floor washing to shop drains.
- Liquid wastes refers to a wide variety
  of flows, such as oil, paint, and process
  water (radiator flushing water, plating
  bath wastewater, etc.) that enter the
  storm drain system.
- Tap water flows are derived from leaks and losses that occur during the distribution of drinking water in the water supply system. Tap water discharges in the storm drain system may be more prevalent in communities

with high loss rates (i.e., greater than 15%) in their potable water distribution system. (source of 15% is from National Drinking Water Clearinghouse http://www.nesc.wvu.edu/ndwc/articles/OT/FA02/Economics\_Water.html)

- Landscape irrigation flows occur when excess potable water used for residential or commercial irrigation ends up in the storm drain system.
- Groundwater and spring water flows
   occur when the local water table rises
   above the bottom elevation of the storm
   drain (known as the invert) and enters
   the storm drain either through cracks
   and joints, or where open channels or
   pipes associated with the MS4 may
   intercept seeps and springs.

Water quality testing is used to conclusively identify flow types found in storm drains. Testing can distinguish illicit flow types (sewage/septage, washwater and liquid wastes) from cleaner discharges (tap water, landscape irrigation and ground water).

Each flow type has a distinct chemical fingerprint. Table 1 compares the pollutant fingerprint for different flow types in Alabama. The chemical fingerprint for each flow type can differ regionally, so it is a good idea to develop your own "fingerprint" library by sampling each local flow type.

In practice, many storm drain discharges represent a blend of several flow types, particularly at larger outfalls that drain larger catchments. For example, groundwater flows often dilute sewage thereby masking its presence. Chapter 12 presents several techniques to help isolate illicit discharges that are blended with cleaner discharges. Illicit discharges are also masked by high volumes of storm water runoff making it

difficult and frequently impossible to detect them during wet weather periods.

## Mode of Entry

Illicit discharges can be further classified based on how they enter the storm drain system. The mode of entry can either be direct or indirect. Direct entry means that the discharge is directly connected to the storm drain pipe through a sewage pipe, shop drain, or other kind of pipe. Direct entry usually produces discharges that are continuous or intermittent. Direct entry usually occurs when two different kinds of "plumbing" are improperly connected. The three main situations where this occurs are:

Sewage cross-connections: A sewer pipe that is improperly connected to the storm drain system produces a continuous discharge of raw sewage to the pipe (Figure 1). Sewage cross-connections can occur in catchments where combined sewers or septic systems are converted to a separate sewer system, and a few pipes get "crossed."

Straight pipe: This term refers to relatively small diameter pipes that intentionally bypass the sanitary connection or septic drain fields, producing a direct discharge into open channels or streams as shown in Figure 2.




Figure 1: Sewer Pipe Discharging to the Storm Drain System

Table 1: Comparative "Fingerprint" (Mean Values) of Flow Types						
Flow Type	Hardness (mg/L as CaCO3)	NH <sub>3</sub> (mg/L)	Potassium (mg/L)	Conductivity (µS/cm)	Fluoride (mg/L)	Detergents (mg/L)
Sewage	50 (0.26)*	25 (0.53)*	12 (0.21)*	1215 (0.45)*	0.7 (0.1)*	9.7 (0.17)*
Septage**	57(0.36)	87 (0.4)	19 (0.42)	502 (0.42)	0.93 (0.39)	3.3 (1.33)
Laundry Washwater	45 (0.33)	3.2 (0.89)	6.5 (0.78)	463.5 (0.88)	0.85 (0.4)	758 (0.27)
Car Washwater	71 (0.27)	0.9 (1.4)	3.6 (0.67)	274 (0.45)	1.2 (1.56)	140 (0.2)
Plating Bath (Liquid Industrial Waste**)	1430 (0.32)	66 (0.66)	1009 (1,24)	10352 (0.45)	5.1 (0.47)	6.8 (0.68)
Radiator Flushing (Liquid Industrial Waste**)	5.6 (1.88)	26 (0.89)	2801 (0.13)	3280 (0.21)	149 (0.16)	15 (0.11)
Tap Water	52 (0.27)	<0.06 (0.55)	1.3 (0.37)	140 (0.07)	0.94 (0.07)	0 (NA)
Groundwater	38 (0.19)	0.06 (1.35)	3.1 (0.55)	149 (0.24)	0.13 (0.93)	0 (NA)
Landscape Irrigation	53 (0.13)	1.3 (1.12)	5.6 (0.5)	180 (0.1)	0.61 (0.35)	0 (NA)

<sup>\*</sup> The number in parentheses after each concentration is the Coefficient of Variation; NA = Not Applicable

\*\* All values are from Tuscaloosa, AL monitoring except liquid wastes and septage, which are from Birmingham, AL.

Sources: Pitt (project support material) and Pitt et al. (1993)



Figure 2: Direct Discharge from a Straight Pipe

Industrial and commercial crossconnections: These occur when a drain pipe is improperly connected to the storm drain system producing a discharge of wash water, process water or other inappropriate flows into the storm drain pipe. A floor shop drain that is illicitly connected to the storm drain system is illustrated in Figure 3. Sewage has the greatest potential to produce direct illicit discharges within any urban subwatershed, regardless of the diverse land uses that it comprises. The most commonly reported sewage-related direct discharges are broken sanitary sewer lines (81% of survey respondents), cross-connections (71% of survey respondents), and straight pipe discharges (38% of survey respondents). (CWP, 2002).

Older industrial areas tend to have a higher potential for illicit cross-connections.

Indirect entry means that flows generated outside the storm drain system enter through storm drain inlets or by infiltrating through the joints of the pipe. Generally, indirect modes of entry produce intermittent or transitory discharges, with the exception of groundwater seepage. The five main modes of indirect entry for discharges include:

Groundwater seepage into the storm drain pipe: Seepage frequently occurs in storm

drains after long periods of above average rainfall. Seepage discharges can be either continuous or intermittent, depending on the depth of the water table and the season. Groundwater seepage usually consists of relatively clean water that is not an illicit discharge by itself, but can mask other illicit discharges. If storm drains are located close to sanitary sewers, groundwater seepage may intermingle with diluted sewage.

Spills that enter the storm drain system at an inlet: These transitory discharges occur when a spill travels across an impervious surface and enters a storm drain inlet. Spills can occur at many industrial, commercial and transport-related sites. A very common example is an oil or gas spill from an accident that then travels across the road and into the storm drain system (Figure 4).

Dumping a liquid into a storm drain inlet: This type of transitory discharge is created when liquid wastes such as oil, grease, paint, solvents, and various automotive fluids are dumped into the storm drain (Figure 5). Liquid dumping occurs intermittently at sites that improperly dispose of rinse water and wash water during maintenance and




Figure 3: A common industrial cross connection is a floor drain that is illicitly connected to a storm drain

cleanup operations. A common example is cleaning deep fryers in the parking lot of fast food operations.

Outdoor washing activities that create flow to a storm drain inlet: Outdoor washing may or may not be an illicit discharge, depending on the nature of the generating site that produces the wash water. For example, hosing off individual sidewalks and driveways may not generate significant flows or pollutant loads. On the other hand, routine washing of fueling areas, outdoor storage areas, and parking lots (power washing), and construction equipment cleanouts may result in unacceptable pollutant loads (Figure 6).

Non-target irrigation from landscaping or lawns that reaches the storm drain system: Irrigation can produce intermittent discharges from over-watering or misdirected sprinklers that send tap water over impervious areas (Figure 7). In some instances, non-target irrigation can produce unacceptable loads of nutrients, organic matter or pesticides. The most common example is a discharge from commercial landscaping areas adjacent to parking lots connected to the storm drain system.




Figure 4: Accident spills are significant sources of illicit discharges to the storm drain system




Figure 5: Dumping at a storm drain inlet



Figure 6: Routine outdoor washing and rinsing can cause illicit discharges




Figure 7: Non-target landscaping irrigation water

Land Use and Potential Generating Sites

Land use can predict the potential for indirect discharges, which are often intermittent or transitory. Many indirect discharges can be identified and prevented using the concept of "generating sites," which are sites where common operations can generate indirect discharges in a community. Both research and program experience indicate that a small subset of generating sites within a broader land use category can produce most of the indirect

discharges. Consequently, the density of potential generating sites within a subwatershed may be a good indicator of the severity of local illicit discharge problems. Some common generating sites within major land use categories are listed in Table 2, and described below

Residential Generating Sites: Failing septic systems were the most common residential discharge reported in 33% of IDDE programs surveyed (CWP, 2002). In addition, indirect residential discharges were

also frequently detected in 20% of the IDDE programs surveyed, which consisted of oil dumping, irrigation overflows, swimming pool discharges, and car washing. Many indirect discharges are caused by common residential behaviors and may not be classified as "illicit" even though they can contribute to water quality problems. With the exception of failing septic systems and oil dumping, most communities have chosen education rather than enforcement as the primary tool to prevent illicit discharges from residential areas.

Commercial Generating Sites: Illicit discharges from commercial sites were reported as frequent in almost 20% of local IDDE programs surveyed (CWP, 2002).

Typical commercial discharge generators included operations such as outdoor washing; disposal of food wastes; car fueling, repair, and washing; parking lot power washing; and poor dumpster management. Recreational areas, such as marinas and campgrounds, were also reported to be a notable source of sewage discharges. It is important to note that not all businesses within a generating category actually produce illicit discharges; generally only a relatively small fraction do. Consequently, on-site inspections of individual businesses are needed to confirm whether a property is actually a generating site.

Sewage can also be linked to significant *indirect* illicit discharges in the form of sanitary sewer overflows (52% of survey respondents), sewage infiltration/inflow (48% of survey respondents), and sewage dumping from recreational vehicles (33% of survey respondents) (CWP, 2002).

Land Use	Generating Site	ctivities That Produce Indirect Discharges  Activity that Produces Discharge		
Residential	<ul> <li>Apartments</li> <li>Multi-family</li> <li>Single Family Detached</li> </ul>	<ul> <li>Car Washing</li> <li>Driveway Cleaning</li> <li>Dumping/Spills (e.g., leaf litter and RV/boat holding tank effluent)</li> <li>Equipment Washdowns</li> <li>Lawn/Landscape Watering</li> <li>Septic System Maintenance</li> <li>Swimming Pool Discharges</li> </ul>		
Commercial	<ul> <li>Campgrounds/RV parks</li> <li>Car Dealers/Rental Car Companies</li> <li>Car Washes</li> <li>Commercial Laundry/Dry Cleaning</li> <li>Gas Stations/Auto Repair Shops</li> <li>Marinas</li> <li>Nurseries and Garden Centers</li> <li>Oil Change Shops</li> <li>Restaurants</li> <li>Swimming Pools</li> </ul>	<ul> <li>Building Maintenance (power washing)</li> <li>Dumping/Spills</li> <li>Landscaping/Grounds Care (irrigation)</li> <li>Outdoor Fluid Storage</li> <li>Parking Lot Maintenance (power washing)</li> <li>Vehicle Fueling</li> <li>Vehicle Maintenance/Repair</li> <li>Vehicle Washing</li> <li>Washdown of greasy equipment and grease traps</li> </ul>		
Industrial	<ul> <li>Auto recyclers</li> <li>Beverages and brewing</li> <li>Construction vehicle washouts</li> <li>Distribution centers</li> <li>Food processing</li> <li>Garbage truck washouts</li> <li>Marinas, boat building and repair</li> <li>Metal plating operations</li> <li>Paper and wood products</li> <li>Petroleum storage and refining</li> <li>Printing</li> </ul>	All commercial activities     Industrial process water or rinse water     Loading and un-loading area washdowns     Outdoor material storage (fluids)		
Institutional	<ul> <li>Cemeteries</li> <li>Churches</li> <li>Corporate Campuses</li> <li>Hospitals</li> <li>Schools and Universities</li> </ul>	<ul> <li>Building Maintenance (e.g., power washing)</li> <li>Dumping/Spills</li> <li>Landscaping/Grounds Care (irrigation)</li> <li>Parking Lot Maintenance (power washing)</li> <li>Vehicle Washing</li> </ul>		
Municipal	<ul> <li>Airports</li> <li>Landfills</li> <li>Maintenance Depots</li> <li>Municipal Fleet Storage Areas</li> <li>Ports</li> <li>Public Works Yards</li> <li>Streets and Highways</li> </ul>	<ul> <li>Building Maintenance (power washing)</li> <li>Dumping/Spills</li> <li>Landscaping/Grounds Care (irrigation)</li> <li>Outdoor Fluid Storage</li> <li>Parking Lot Maintenance (power washing)</li> <li>Road Maintenance</li> <li>Spill Prevention/Response</li> <li>Vehicle Fueling</li> <li>Vehicle Maintenance/Repair</li> <li>Vehicle Washing</li> </ul>		